

Release the Inner Goddess



QUESTIONS OR COMMENTS
For Replacement Parts or Hand Cream

ARTEMIS WOMAN®, LLC
P. O. Box 1242, Weston CT 06883
1 877 212 1560
www.artemiswoman.com

Appliance and Accessories Made in CHINA
Hand Cream Made in U.S.A.



HAND SPA GIFT SET



USE AND CARE GUIDE

FOR A REVOLUTIONARY NEW LINE OF
SKIN CARE PRODUCTS

◆ HK-100

Congratulations on your purchase
of the Artemis Woman®
Hand Spa Gift Set!

We at Artemis Woman wish to thank you for
supporting Artemis Woman® products with your
purchase. As with all Artemis Woman® products,
your Hand Spa Gift Set was manufactured with
utmost care and attention to quality.

The Artemis Woman® Hand Spa Gift Set is the
perfect treat for your hard working hands.

IMPORTANT SAFETY INSTRUCTIONS

When using any appliance, basic
safety precautions should always be
followed, including the following.

READ ALL INSTRUCTIONS BEFORE USING.

SPECIAL WARNINGS

1. Keep out of reach of children.
2. Use this appliance only for its intended use as described in this manual. Do not use attachments not recommended by Artemis Woman®.
3. Do not apply extreme pressure when using device or replacing broken attachments or product may become damaged or broken.
4. Do not share this product with others.
5. Do not immerse the unit in water. Do not use in bathtub or shower.
6. Use only AA alkaline batteries.
7. Do not mix old and new batteries. Batteries may become damaged or leak.
8. Make sure to insert batteries according to the markings on manicure appliance.

Battery Warnings

1. Use only AA alkaline batteries.
2. Do not mix old and new batteries. Batteries may become damaged or leak.
3. Make sure to insert batteries according to the markings on the Manicure Tool.

HAND SPA INCLUDES

1. Battery operated manicure tool (1AA battery required, not included)
2. 2 shaper attachments (1 coarse, 1 fine)
3. 4 filers
4. 2 buffers
5. 1 cuticle pusher
6. Nail clipper
7. Nail brush
8. Organza storage pouch
9. 3.75oz tube Tourmaline Hand Cream
10. Guide to Gem Therapy Skin Care



PLEASE SAVE THESE INSTRUCTIONS

1

HAND SPA FEATURES



Your Hand Spa includes:

- Battery operated manicure tool (1AA battery required, not included)
- 2 shaper attachments (1 coarse, 1 fine)
- 4 filers
- 2 buffers
- 1 cuticle pusher
- Nail clipper
- Nail brush
- Organza storage pouch
- 3.75oz tube Tourmaline Hand Cream
- Guide to Gem Therapy Skin Care

4

USING YOUR HAND SPA

Step 1: Clean Hands and Nails

Wash and thoroughly dry hands with soap and the nail brush to remove any dirt or oils, making sure to clean under the nails.

Step 2: File and Shape Nails

1. If you want to significantly shorten your nails, use the nail clipper first to achieve the desired length before shaping and filing.
2. Place one of the two silver shapers on the manicure tool (remember to line up the two pegs on back of the attachment with the two holes on the manicure tool!)
 - a. For thin, fragile nails, use the finer shaper attachment.
 - b. For thicker, stronger nails, use coarser shaper attachment.
3. Begin to shape your nails to desired size and shape by gently guiding the attachment over your nail surface (only light pressure is needed). For maximum strength, file nails straight across,

HOW TO INSTALL/REPLACE BATTERIES

2

- Slide off back of battery compartment on the manicure tool.
- Insert 1 AA battery in direction indicated on the inside of the manicure tool.
- Replace battery cover by sliding back on until you hear a “click”

HOW TO INSTALL AND REMOVE ATTACHMENTS

- Ensure unit is turned off.
- Select your desired attachment
- Place attachment on the manicure tool by lining up the two small pegs on the back of the attachment with the two small holes on the manicure tool. The attachments only fit in one direction, so ensure that the pegs and holes are lined up properly!

rounding them slightly at the sides (filing nails into points will weaken them). Filing nails in this back-and-forth motion will help reduce splitting.

4. Repeat using one of the four filing attachments to gently file and smooth the edges of your nails.

Step 3: Apply Hand and Cuticle Cream

1. Apply a small amount of Healing Gems® Hand and Cuticle Cream to the cuticles on each finger. Gently rub on cuticles and nail bed.
2. Apply more cream to the hands and rub hands together, massaging the cream into the hands and forearms.

Step 4: Pushing back the cuticles

Now that your cuticles are softened, place the white cuticle pusher on the manicure appliance, and gently push back each cuticle using the tip of the cuticle pusher. Gently pushing the cuticle will encourage healthy nail growth and achieve an even surface to apply nail polish.

You will hear a click when the attachment is secured.

- To remove, simply pull off the attachment from the manicure tool.

OPERATING INSTRUCTIONS

For the ultimate spa manicure, find a quiet spot, take a deep breath and relax!

You may also want to have a small bowl of warm water, soap, and hand towel handy.

If you plan to polish your nails, collect your nail polish, polish remover and cotton balls before your start.

3

Step 5: Buffing the nails

- Remove excess oil or cream from the nail surface with nail polish remover (not included) or warm water, soap and the nail brush. Attach a buffer attachment to the manicure/pedicure tool and begin to buff the nail surface, gently working the buffer back and forth to smooth ridges and polish the nail surface. Note: Be sure to keep the buffer moving at all times - keeping it in one position may cause the buffer to get hot with friction. You can either maintain your natural nail finish or apply nail polish (not included) to complete the manicure.

CLEANING YOUR MANICURE APPLIANCE

- To clean the manicure appliance, use a damp cloth to clean the surface of the appliance. You can use a mild detergent if necessary but do not use paint thinner, benzene or other cleaning agents as it can damage the finish.
- Do not immerse the unit in water. Do not use in bathtub or shower.

5

ARTEMIS WOMAN® 1-YEAR LIMITED WARRANTY

6

Artemis Woman® LLC warrants this product against any defects that are due to faulty material or workmanship for one year from the original date of consumer purchase. This warranty does not include damage to the product resulting from accident or misuse.

This warranty covers all defects in workmanship or materials in the mechanical and electrical parts, arising under normal usage and care, in this Artemis Woman® product for a period of one year from the date of purchase provided you are able to present a valid proof-of-purchase. A valid proof-of-purchase is a retailer receipt specifying item, date purchased, and cost of item. A retailer gift receipt with date of purchase and item is also an acceptable proof-of-purchase. Product is intended for household use only. Any commercial use voids the warranty.

If the product should become defective within the warranty period, we will repair it or elect to replace it free of charge. We will return your product, transportation charges prepaid, provided it is delivered prepaid to:

Artemis Woman, LLC., P.O. Box 1242, Weston, CT 06883. Include a letter stating the reason for the return and the original purchase receipt.

ARTEMIS WOMAN® SHALL NOT BE RESPONSIBLE FOR ANY INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES.

This warranty gives you specific legal rights and you may also have other rights which vary from state to state. Some states do not allow the exclusion or limitation of incidental, special or consequential damages.

ARTEMIS WOMAN® MONEY BACK OFFER

If within 90 days after you have purchased your Artemis Woman® Hand Spa Gift Set you are not satisfied and would like a refund, take back the item and sales slip indicating purchase price and the date of purchase to the retailer from whom the item was purchased. Artemis Woman® will reimburse all retailers who accept the item within 90 days from the date of purchase. If you have any questions concerning the money back guarantee, please call 1-877-212-1560.